



NOTES:

1. MORTAR FINISH NOT REQUIRED WHEN CURB IS POURED BY A MACHINE, BUT CURB WILL HAVE THE SAME OUTSIDE DIMENSIONS.
2. WHEN CONCRETE CURB IS TO BE PLACED ON EXISTING CONCRETE BASE, USE #4 DEFORMED BARS, 10" LONG, 24" O.C., DOWELLED, AND SET IN QUICK SETTING CEMENT MORTAR
3. REDWOOD EXPANSION JOINTS SHALL BE INSTALLED IN CURB AT ALL PAVEMENT EXPANSION JOINTS.

THE CITY OF ROSENBERG, FORT BEND COUNTY, TEXAS  
DEPARTMENT OF PUBLIC WORKS

## CONCRETE CURB

DESIGN:  
CAK

CAD:  
STAFF

SCALE  
NTS

DATE:  
12/10

DRAWING:  
P-100a